



INSTRUCTIONS FOR: TRANSPORTACAR TROLLEY MODEL: RE901


Your new Trolley is produced and manufactured to a high standard of dependability and will, if used according to these instructions and properly maintained, give you years of trouble free performance.



IMPORTANT: READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS AND CAUTIONS. USE THIS TROLLEY CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. RETAIN THESE INSTRUCTIONS FOR FUTURE USE.

1. SAFETY PRECAUTIONS

- 3 Ensure the trolley is in sound condition and good working order. Take action for immediate repair or replacement of damaged parts. *Use genuine parts only. The use of improper parts may be dangerous and will invalidate the warranty.*
- p **WARNING!** Prepare the vehicle ready for resting and moving on the trolley. Ensure the vehicle will not move, tip, fall etc once it has been seated on the trolley. Take any necessary precautions to protect persons, property and equipment when using this trolley.
- 3 Locate the trolley in a suitable, well lit working area.
- 3 Keep working area clean and tidy and free from unrelated materials.
- 3 Use trolley on level and solid ground, preferably concrete. *Avoid tarmac as trolley may sink in.*
- 3 Ensure the vehicle engine is switched off .
- 3 Ensure there are no passengers in the vehicle.
- 3 Ensure all non-essential persons keep a safe distance whilst the trolley is in use.
- 3 Only place trolley under those lifting points recommended by vehicle manufacturer *(see vehicle hand book).*
- 3 Check the lifting point is stable and correctly held in trolley supports.
- 3 Ensure the trolley wheels are free to move and that there are no obstructions.
- 3 Ensure you have a clear view and necessary assistance when transporting vehicle.
- 3 Ensure there are no persons or obstructions beneath the vehicle before moving.
- 3 When stationary, always lock the two brake wheels.
- 7 DO NOT operate the trolley if damaged.
- 7 DO NOT allow untrained persons to operate the trolley.
- 7 DO NOT exceed the rated capacity of the trolley.
- p **WARNING!** DO NOT use the trolley to hold and move a vehicle which is unstable.
- 7 DO NOT allow the vehicle to move on the trolley.
- 7 DO NOT move vehicle if there is a risk of spillage of fuel, battery acid, or other dangerous substances.
- 7 DO NOT work under the vehicle unless supported by axle stands which have been correctly positioned.
- 7 DO NOT ride on the trolley.
- 7 DO NOT use the trolley without appropriate supports.
- 7 DO NOT use the trolley for purposes other than which it is intended.
- 3 When not in use store trolley in a safe, dry, childproof area.



2. INTRODUCTION & SPECIFICATIONS


Heavy duty steel frame-work suitable for supporting partly dismantled or badly damaged vehicles. Enables easy movement around bodyshop. Supports interchangeable between v-crutches and sill clamps. Supports and clamps adjustable for height and overall width. The trolley is fitted with 2 brake locking wheels.

Capacity2000kg
Min. height250mm
Max. height310mm
Min. width*1035mm
Max. width*1430mm
Length600mm

*Widths measured between the centre of the trolley points

3. ASSEMBLY

- 3.1. Assemble four wheels with nuts, spring washer, washers, and bolts. Ensure that the two locking wheels are at the same end.
- 3.2. Remove extension arm (fig1.C) from main beam undoing knob (A) and lifting arm off.
- 3.3. Assemble main beam (C) to wheel frames by fixing with four bolts, spring washers, washers and nuts at each end (B).
- 3.4. Check that all connections are tight and replace the extension arm (C) by screwing knob (A) into the holding plate set inside the frame of the main beam.
- 3.5. Screw the appropriate supports into the end of the extension arm at point (X) and place the unused supports in their storage eyes (D).



WARNING! Before use ensure Section 1 safety instructions are read and understood.

- 3.6. Check and prepare the vehicle as mentioned in the safety instructions ensuring the ground on which the trolley is to travel is level and solid (not tarmacadam).
- 3.7. Position the trolley supports under the vehicle manufacturer's recommended lifting point. If using the sill clamps ensure they are correctly fitted and tightened. Check that the vehicle is secure and there are no persons or obstacles beneath the vehicle or in the path of transportation. Ensure the wheel brakes are unlocked and move the vehicle.
- 3.8. When the trolley destination is reached, the trolley wheel brakes must be applied to stop further movement. DO NOT use trolley as a support stand for working on, or under, the vehicle. The trolley is designed for manoeuvring only.

4. MAINTENANCE

- 4.1. Before each use check for broken, cracked, bent, or loose parts, or any visible damage. If any suspect item is found remove trolley from service and take necessary action to remedy the problem. DO NOT use the trolley if believed to have been subjected to abnormal load or shock load.
- 4.2. Keep the trolley clean and periodically oil the wheel bearings.

5. DECLARATION OF CONFORMITY

Declaration of Conformity We, the sole importer into the UK, declare that the product listed below is in conformity with the following EEC standards and directives.

**TRANSPORTACAR TROLLEY
Model: RE901**

93/68/EEC CE Marking Directive
98/37/EC Machinery Directive (S.I.1992/3073 & Amendments)



The construction file for this product is held by the Manufacturer and may be inspected, by a national authority, upon request to Jack Sealey Ltd.

Signed by Mark Sweetman

29th June 2000

For Jack Sealey Ltd. Sole importer into the UK of Sealey Quality Machinery

NOTE: It is our policy to continually improve products and as such we reserve the right to alter data, specifications and component parts without prior notice.

IMPORTANT: No liability is accepted for incorrect use of this product.

WARRANTY: Guarantee is 12 months from purchase date, proof of which will be required for any claim.

INFORMATION: Call 01284 757525 for our catalogue & promotions. Leave your full name, address & postcode.



Sole UK Distributor,
Sealey Group, Bury St. Edmunds, Suffolk.



01284 757500



01284 703534

E-mail: sales@sealey.co.uk